

Firmware Release Note

Prestige 2302RL
Standard version

Release 3.60(MQ.0)C0

Date: July. 07, 2005
Author: Alvin Lin

ZyXEL Prestige 2302RL Standard Version Release 3.60(MQ.0)C0 Release Note

Date: July 07, 2005

Supported Platforms:

ZyXEL Prestige 2302RL

Versions:

ZyNOS Version: V3.60(MQ.0)C0 | 07/07/2005 10:18:46

Bootbase Version: V1.08 | 04/15/2005 17:12:54

Notes:

Features:

Modification in V 3.60(MQ.0)C0 | 07/07/2005

Modification in V 3.60(MQ.0)b4 | 06/27/2005

1. [BUG FIX] [SPR No: 050627304]

Symptom: On Wizard ISP Parameters help page, the product name is shown ZyAIR.

2. [BUG FIX] [SPR No: 050627305]

Symptom: Wizard setup function doesn't work properly. The parameters of step1,2,3 CANNOT be saved

3. [BUG FIX] [SPR No: 050627306]

Symptom: The system name can accept "@" and ".", but it is NOT mentioned on wizard general setup help page and SYSTEM general help page.

4. [BUG FIX] [SPR No: 050627309]

Symptom: There is an incorrect boldface word "advanced" on PHONEBOOK/ Call forward help page.

5. [BUG FIX] [SPR No: 050627312]

Symptom: Call transfer failed. At step7, B and C should converse, but they don't.

6. [BUG FIX] [SPR No: 050627313]

Symptom: Sending Log will occur exception.

7. [BUG FIX] [SPR No: 050627314]

Symptom: Bandwidth Management GUI.

8. [BUG FIX] [SPR No: 050627315]

Symptom: DUT cannot send the log to mail server.

Modification in V 3.60(MQ.0)b3 | 06/13/2005

1. [ENHANCEMENT]

- Add traffic redirect full functions
- Remove PPTP
- Support MAC long term solution
- Adjust VOIP tasks priority to handle VOIP call smoothly in heavy network traffic situation.
- Add static DHCP function

Annex A CI Command List

| Command Class List Table | | |
|---|-------------------------------------|--|
| System Related Command | Exit Command | Ethernet Related Command |
| | | IP Related Command |
| | PPP Related Command | |
| | | Firewall Related Command |
| Configuration Related Command | SMT Related Command | |

System Related Command

[Home](#)

| Command | | | | Description |
|---------|-------------|---------|---|---|
| sys | | | | |
| | adjtime | | | retrive date and time from Internet |
| | cbuf | | | |
| | | display | [a f u] | display cbuf a: all f: free u: used |
| | | cnt | | cbuf static |
| | | | display | display cbuf static |
| | | | clear | clear cbuf static |
| | baud | | <1..5> | change console speed |
| | callhist | | | |
| | | display | | display call history |
| | | remove | <index> | remove entry from call history |
| | clear | | | clear the counters in GUI status menu |
| | countrycode | | [countrycode] | set country code |
| | date | | [year month date] | set/display date |
| | domainname | | | display domain name |
| | edit | | <filename> | edit a text file |
| | enhanced | | | return OK if commands are supported for PWC purposes |
| | errctl | | [level] | set the error control level 0:crash no save,not in debug mode (default) 1:crash no save,in debug mode 2:crash save,not in debug mode 3:crash save,in debug mode |
| | event | | | |
| | | display | | display tag flags information |
| | | trace | | display system event information |
| | | | display | display trace event |
| | | | clear <num> | clear trace event |
| | extraphnum | | | maintain extra phone numbers for outcalls |
| | | add | <set 1-3> <1st phone num> [2nd phone num] | add extra phone numbers |
| | | display | | display extra phone numbers |
| | | node | <num> | set all extend phone number to remote node <num> |
| | | remove | <set 1-3> | remove extra phone numbers |
| | | reset | | reset flag and mask |
| | feature | | | display feature bit |
| | fid | | | |
| | | display | | display function id list |
| | firmware | | | display ISDN firmware type |
| | hostname | | [hostname] | display system hostname |
| | iface | | | |

ZyXEL Confidential

| | | | | |
|--|-----------|----------|--|---|
| | | disp | [#] | display iface list |
| | isr | | [all used free] | display interrupt service routine |
| | interrupt | | | display interrupt status |
| | log | | | |
| | | category | | |
| | | | access [0:none/1:log] | record the access control logs |
| | | | attack [0:none/1:log/2:alert/3:both] | record and alert the firewall attack logs |
| | | | display | display the category setting |
| | | | error [0:none/1:log/2:alert/3:both] | record and alert the system error logs |
| | | | ipsec [0:none/1:log] | record the access control logs |
| | | | | |
| | | | mten [0:none/1:log] | record the system maintenance logs |
| | | | upnp [0:none/1:log] | record upnp logs |
| | | | urlblocked [0:none/1:log/2:alert/3:both] | record and alert the web blocked logs |
| | | | urlforward [0:none/1:log] | record web forward logs |
| | | clear | | clear log |
| | | display | | display all logs |
| | | errlog | | |
| | | | clear | display log error |
| | | | disp | clear log error |
| | | | online | turn on/off error log online display |
| | | load | | load the log setting buffer |
| | | mail | | |
| | | | alertAddr [mail address] | send alerts to this mail address |
| | | | display | display mail setting |
| | | | logAddr [mail address] | send logs to this mail address |
| | | | schedule display | display mail schedule |
| | | | schedule hour [0-23] | hour time to send the logs |
| | | | schedule minute [0-59] | minute time to send the logs |
| | | | schedule policy [0:full/1:hourly/2:daily/3:weekly/4:non e] | mail schedule policy |
| | | | schedule week [0:sun/1:mon/2:tue/3:wed/4:thu/5:fri/6: sat] | weekly time to send the logs |
| | | | server [domainName/IP] | mail server to send the logs |
| | | | subject [mail subject] | mail subject |
| | | save | | save the log setting buffer |
| | | syslog | | |
| | | | active [0:no/1:yes] | active to enable unix syslog |
| | | | display | display syslog setting |
| | | | facility [Local ID(1-7)] | log the messages to different files |
| | | | server [domainName/IP] | syslog server to send the logs |
| | mbuf | | | |
| | | cnt | | |
| | | | disp | display system mbuf count |
| | | | clear | clear system mbuf count |
| | | link | link | list system mbuf link |
| | | pool | <id> [type] | list system mbuf pool |
| | | status | | display system mbuf status |
| | | disp | <address> | display mbuf status |
| | | debug | [on off] | |
| | memory | | <address> <length> | display memory content |

ZyXEL Confidential

| | | | | |
|--|-----------|-----------|--|---|
| | memwrite | | <address> <len> [data list ...] | write some data to memory at <address> |
| | memwl | | <address> | write long word to memory at <address> |
| | memrl | | <address> | read long word at <address> |
| | memutil | | | |
| | | usage | | display memory allocate and heap status |
| | | mqueue | <address> <len> | display memory queues |
| | | mcell | mid [f u] | display memory cells by given ID |
| | | msecs | [a f u] | display memory sections |
| | | mtstart | <n-mcell> | start memory test |
| | | mtstop | | stop memory test |
| | | mtalloc | <size> [n-mcell] | allocate memory for testing |
| | | mtfree | <start-idx> [end-idx] | free the test memory |
| | model | | | display server model name |
| | proc | | | |
| | | display | | display all process information |
| | | stack | [tag] | display process's stack by a give TAG |
| | | pstatus | | display process's status by a give TAG |
| | queue | | | |
| | | display | [a f u] [start#] [end#] | display queue by given status and range numbers |
| | | ndisp | [qid] | display a queue by a given number |
| | quit | | | quit CI command mode |
| | reboot | | [code] | reboot system code = 0 cold boot, = 1 immediately boot = 2 bootModule debug mode |
| | reslog | | | |
| | | disp | | display resources trace |
| | | clear | | clear resources trace |
| | stdio | | [second] | change terminal timeout value |
| | time | | [hour [min [sec]]] | display/set system time |
| | timer | | | |
| | | disp | | display timer cell |
| | | trace | [on off] | set/display timer information online |
| | | start | [tmValue] | start a timer |
| | | stop | <ID> | stop a timer |
| | trcdisp | | | monitor packets |
| | trclog | | | |
| | | switch | [on off] | set system trace log |
| | | online | [on off] | set on/off trace log online |
| | | level | [level] | set trace level of trace log #:1-10 |
| | | type | <bitmap> | set trace type of trace log |
| | | disp | | display trace log |
| | | clear | | clear trace |
| | | call | | display call event |
| | | encapmask | [mask] | set/display tracelog encapsulation mask |
| | trcpacket | | | |
| | | create | <entry> <size> | create packet trace buffer |
| | | destroy | | packet trace related commands |
| | | channel | <name> [none incoming outgoing bothway] | <channel name>=enet0,sdsl00, fr0 set packet trace direction for a given channel |
| | | string | | enable smt trace log |
| | | switch | [on off] | turn on/off the packet trace |
| | | disp | | display packet trace |

ZyXEL Confidential

| | | | | |
|--|----------|----------|---|--|
| | | udp | | send packet trace to other system |
| | | | switch [on off] | set tracepacket upd switch |
| | | | addr <addr> | send trace packet to remote udp address |
| | | | port <port> | set tracepacket udp port |
| | | parse | [[start_idx], end_idx] | parse packet content |
| | | brief | | display packet content briefly |
| | version | | | display RAS code and driver version |
| | view | | <filename> | view a text file |
| | wdog | | | |
| | | switch | [on off] | set on/off wdog |
| | | cnt | [value] | display watchdog counts value: 0-34463 |
| | romreset | | | restore default romfile |
| | server | | | |
| | | access | <telnet ftp web icmp snmp dns> <value> | set server access type |
| | | load | | load server information |
| | | disp | | display server information |
| | | port | <telnet ftp web snmp> <port> | set server port |
| | | save | | save server information |
| | | secureip | <telnet ftp web icmp snmp dns> <ip> | set server secure ip addr |
| | spt | | | |
| | | dump | | dump spt raw data |
| | | | root | dump spt root data |
| | | | rn | dump spt remote node data |
| | | | user | dump spt user data |
| | | | slot | dump spt slot data |
| | | save | | save spt data |
| | | size | | display spt record size |
| | | clear | | clear spt data |
| | cmgr | | | |
| | | trace | | |
| | | | disp <ch-name> | show the connection trace of this channel |
| | | | clear <ch-name> | clear the connection trace of this channel |
| | | cnt | <ch-name> | show channel connection related counter |
| | socket | | | display system socket information |
| | filter | | | |
| | | clear | | clear filter statistic counter |
| | | disp | | display filter statistic counters |
| | | sw | [on off] | set filter status switch |
| | | set | <set> | display filter rule |
| | | | | |
| | | netbios | | |
| | | | disp | display netbios filter status |
| | | | config <0:LAN to WAN, 1:WAN to LAN, 2:LAN to DMZ, 3:IPSec passthrough, 4:Trigger Dial> <on off> | config netbios filter |
| | ddns | | | |
| | | debug | <level> | enable/disable ddns service |
| | | display | <iface name> | display ddns information |
| | | restart | <iface name> | restart ddns |
| | | logout | <iface name> | logout ddns |
| | cpu | | | |
| | | display | | display CPU utilization |

Exit Command

[Home](#)

| Command | | | | Description |
|---------|--|--|--|---------------|
| exit | | | | exit smt menu |

Ethernet Related Command

[Home](#)

| Command | | | | Description |
|---------|-----------|--------|---------------------------------|--|
| ether | | | | |
| | config | | | display LAN configuration information |
| | driver | | | |
| | | cnt | | |
| | | | disp <name> | display ether driver counters |
| | | | clear <name> | clear ether driver counters |
| | | iface | <ch_name> <num> | send driver iface |
| | | ioctl | <ch_name> | Useless in this stage. |
| | | mac | <ch_name> <mac_addr> | Set LAN Mac address |
| | | reg | <ch_name> | display LAN hardware related registers |
| | | rxmod | <ch_name> <mode> | set LAN receive mode. mode: 1: turn off receiving 2: receive only packets of this interface 3: mode 2+ broadcast 5: mode 2 + multicast 6: all packets |
| | | status | <ch_name> | see LAN status |
| | | init | <ch_name> | initialize LAN |
| | version | | | see ethernet device type |
| | pkttest | | | |
| | | disp | | |
| | | | packet <level> | set ether test packet display level |
| | | | event <ch> [on/off] | turn on/off ether test event display |
| | | sap | [ch_name] | send sap packet |
| | | arp | <ch_name> <ip-addr> | send arp packet to ip-addr |
| | | mem | <addr> <data> [type] | write memory data in address |
| | test | | <ch_id> <test_id> [arg3] [arg4] | do LAN test |
| | pncconfig | | <ch_name> | do pnc config |
| | mac | | <src_ch> <dest_ch> <ipaddr> | fake mac address |

IP Related Command

[Home](#)

| Command | | | | Description |
|---------|--------------|---------|-----------------------------|-------------------------|
| ip | | | | |
| | address | | [addr] | display host ip address |
| | loopbackaddr | | <IP1> [IP2] | Set loopback address. |
| | alias | | <iface> | alias iface |
| | aliasdis | | <0 1> | disable alias |
| | arp | | | |
| | | status | <iface> | display ip arp status |
| | | add | <hostid> ether <ether addr> | add arp information |
| | | resolve | <hostid> | resolve ip-addr |
| | | drop | <hostid> [hardware] | drop arp |
| | | flush | | flush arp table |
| | | publish | | add proxy arp |

ZyXEL Confidential

| | | | | |
|--|----------|-----------|--|---|
| | dhcp | | <iface> | |
| | | client | | |
| | | | release | release DHCP client IP |
| | | | renew | renew DHCP client IP |
| | | mode | <server relay none client> | set dhcp mode |
| | | relay | server <serverIP> | set dhcp relay server ip-addr |
| | | reset | | reset dhcp table |
| | | server | | |
| | | | probecount <num> | set dhcp probe count |
| | | | dnsserver <IP1> [IP2] [IP3] | set dns server ip-addr |
| | | | winsserver <winsIP1> [<winsIP2>] | set wins server ip-addr |
| | | | gateway <gatewayIP> | set gateway |
| | | | hostname <hostname> | set hostname |
| | | | initialize | fills in DHCP parameters and initializes (for PWC purposes) |
| | | | leasetime <period> | set dhcp leasetime |
| | | | netmask <netmask> | set dhcp netmask |
| | | | pool <startIP> <numIP> | set dhcp ip pool |
| | | | renewaltime <period> | set dhcp renew time |
| | | | rebindtime <period> | set dhcp rebind time |
| | | | reset | reset dhcp table |
| | | | server <serverIP> | set dhcp server ip for relay |
| | | | dnsorder [router isp] | set dhcp dns order |
| | | status | [option] | show dhcp status |
| | | static | | |
| | | | delete <num> all | delete static dhcp mac table |
| | | | display | display static dhcp mac table |
| | | | update <num> <mac> <ip> | update static dhcp mac table |
| | dns | | | |
| | | query | | |
| | | | address <ipaddr> [timeout] | resolve ip-addr to name |
| | | | debug <num> | enable dns debug value |
| | | | name <hostname> [timeout] | resolve name to ip-addr |
| | | | status | display dns query status |
| | | | table | display dns query table |
| | | server | <primary> [secondary] [third] | set dns server |
| | | stats | | |
| | | | clear | clear dns statistics |
| | | | disp | display dns statistics |
| | | table | | display dns table |
| | httpd | | | |
| | | debug | [on off] | set http debug flag |
| | icmp | | | |
| | | echo | [on off] | set icmp echo response flag |
| | | data | <option> | select general data type |
| | | status | | display icmp statistic counter |
| | | trace | [on off] | turn on/off trace for debugging |
| | | discovery | <iface> [on off] | set icmp router discovery flag |
| | ifconfig | | [iface] [ipaddr] [broadcast <addr> [mtu <value> dynamic] | configure network interface |
| | ifdrop | | <iface> | check if iface is available. |
| | ping | | <hostid> | ping remote host |
| | pong | | <hostid> [<size> <time-interval>] | pong remote host |

ZyXEL Confidential

| | | | | |
|--|---------|----------------|--|--|
| | route | | | |
| | | status | [if] | display routing table |
| | | add | <dest_addr default>[/<bits>] <gateway> [<metric>] | add route |
| | | addiface | <dest_addr default>[/<bits>] <gateway> [<metric>] | add an entry to the routing table to iface |
| | | addprivate | <dest_addr default>[/<bits>] <gateway> [<metric>] | add private route |
| | | drop | <host addr> [/<bits>] | drop a route |
| | | flush | | flush route table |
| | | lookup | <addr> | find a route to the destination |
| | | errcnt | | |
| | | | disp | display routing statistic counters |
| | | | clear | clear routing statistic counters |
| | status | | | display ip statistic counters |
| | adjTcp | | <iface> [<mss>] | adjust the TCP mss of iface |
| | udp | | | |
| | | status | | display udp status |
| | rip | | | |
| | | accept | <gateway> | drop an entry from the RIP refuse list |
| | | activate | | enable rip |
| | | merge | [on/off] | set RIP merge flag |
| | | refuse | <gateway> | add an entry to the rip refuse list |
| | | request | <addr> [port] | send rip request to some address and port |
| | | reverse | [on/off] | RIP Poisoned Reverse |
| | | status | | display rip statistic counters |
| | | trace | | enable debug rip trace |
| | | mode | | |
| | | | <iface> in [mode] | set rip in mode |
| | | | <iface> out [mode] | set rip out mode |
| | | dialin user | [show/in/out/both/none] | show dialin user rip direction |
| | tcp | | | |
| | | ceiling | [value] | TCP maximum round trip time |
| | | floor | [value] | TCP minimum rtt |
| | | irtt | [value] | TCP default init rtt |
| | | kick | <tcb> | kick tcb |
| | | limit | [value] | set tcp output window limit |
| | | max-incomplete | [number] | Set the maximum number of TCP incomplete connection. |
| | | mss | [value] | TCP input MSS |
| | | reset | <tcb> | reset tcb |
| | | rtt | <tcb> <value> | set round trip time for tcb |
| | | status | [tcb] [<interval>] | display TCP statistic counters |
| | | syndata | [on/off] | TCP syndata piggyback |
| | | trace | [on/off] | turn on/off trace for debugging |
| | | window | [tcb] | TCP input window size |
| | samenet | | <iface1> [<iface2>] | display the ifaces that in the same net |
| | uninet | | <iface> | set the iface to uninnet |
| | tftp | | | |
| | | support | | prtn if tfpt is support |
| | | stats | | display tftp status |
| | xparent | | | |
| | | join | <iface1> [<iface2>] | join iface2 to iface1 group |
| | | break | <iface> | break iface to leave ipxparent group |

ZyXEL Confidential

| | | | | |
|--|-----------|------------|--------------------------------------|---|
| | antiprobe | | <0 1> 1:yes 0:no | set ip anti-probe flag |
| | igmp | | | |
| | | debug | [level] | set igmp debug level |
| | | forwardall | [on/off] | turn on/off igmp forward to all interfaces flag |
| | | querier | [on/off] | turn on/off igmp stop query flag |
| | | iface | | |
| | | | <iface> grouptm <timeout> | set igmp group timeout |
| | | | <iface> interval <interval> | set igmp query interval |
| | | | <iface> join <group> | join a group on iface |
| | | | <iface> leave <group> | leave a group on iface |
| | | | <iface> query | send query on iface |
| | | | <iface> rsptime [time] | set igmp response time |
| | | | <iface> start | turn on of igmp on iface |
| | | | <iface> stop | turn off of igmp on iface |
| | | | <iface> ttl <threshold> | set ttl threshold |
| | | | <iface> v1compat [on/off] | turn on/off v1compat on iface |
| | | robustness | <num> | set igmp robustness variable |
| | | status | | dump igmp status |
| | pr | | | |
| | | clear | | clear ip pr table counter information |
| | | disp | | dump ip pr table counter information |
| | | switch | | turn on/off ip pr table counter flag |
| | nat | | | |
| | | timeout | | |
| | | | gre [timeout] | set nat gre timeout value |
| | | | iamt [timeout] | set nat iamt timeout value |
| | | | generic [timeout] | set nat generic timeout value |
| | | | reset [timeout] | set nat reset timeout value |
| | | | tcp [timeout] | set nat tcp timeout value |
| | | | tcpother [timeout] | set nat tcp other timeout value |
| | | update | | create nat system information from spSysParam |
| | | iamt | | display nat iamt information |
| | | iface | <iface> | show nat status of an interface |
| | | lookup | <rule set> | display nat lookup rule |
| | | new-lookup | <rule set> | display new nat lookup rule |
| | | loopback | [on/off] | turn on/off nat loopback flag |
| | | reset | <iface> | reset nat table of an iface |
| | | server | | |
| | | | disp | display nat server table |
| | | | load <set id> | load nat server information from ROM |
| | | | save | save nat server information to ROM |
| | | | clear <set id> | clear nat server information |
| | | | edit active <yes/no> | set nat server edit active flag |
| | | | edit svrport <start port> [end port] | set nat server server port |
| | | | edit intport <start port> [end port] | set nat server forward port |
| | | | edit remotehost <start ip> [end ip] | set nat server remote host ip |
| | | | edit leasetime [time] | set nat server lease time |
| | | | edit rulename [name] | set nat server rule name |
| | | | edit forwardip [ip] | set nat server server ip |
| | | | edit protocol [protocol id] | set nat server protocol |
| | | service | | |
| | | | irc [on/off] | turn on/off irc flag |
| | | resetport | | reset all nat server table entries |
| | | incikeport | [on/off] | turn on/off increase ike port flag |

PPP Related Command

[Home](#)

| Command | | | | Description |
|---------|-------------|--------|-------------------|---|
| ppp | | | | |
| | autotrigger | | | |
| | | on | <remoteNodeIndex> | turn on packet trigger, default is enable |
| | | off | <remoteNodeIndex> | turn off packet trigger |
| | | status | | show autotrigger status |
| | retry | | <interval> | adjust PPP retrial interval |

Configuration Related Command

[Home](#)

| Command | | | | | Description |
|----------|----------|--------------------|--|--|---|
| config | | | | | The parameters of config are listed below. |
| edit | firewall | active <yes no> | | | Activate or deactivate the saved firewall settings |
| retrieve | firewall | | | | Retrieve current saved firewall settings |
| save | firewall | | | | Save the current firewall settings |
| display | firewall | | | | Displays all the firewall settings |
| | | set <set#> | | | Display current entries of a set configuration; including timeout values, name, default-permit, and number of rules in the set. |
| | | set <set#> | rule <rule#> | | Display current entries of a rule in a set. |
| | | attack | | | Display all the attack alert settings in PNC |
| | | e-mail | | | Display all the e-mail settings in PNC |
| | | ? | | | Display all the available sub commands |
| | | e-mail | mail-server <mail server IP> | | Edit the mail server IP to send the alert |
| | | | return-addr <e-mail address> | | Edit the mail address for returning an email alert |
| | | | e-mail-to <e-mail address> | | Edit the mail address to send the alert |
| | | | policy <full hourly daily weekly> | | Edit email schedule when log is full or per hour, day, week. |
| | | | day <sunday monday tuesday wednesday thursday friday saturday> | | Edit the day to send the log when the email policy is set to Weekly |
| | | | hour <0~23> | | Edit the hour to send the log when the email policy is set to daily or weekly |
| | | | minute <0~59> | | Edit the minute to send to log when the email policy is set to daily or weekly |
| | | | Subject <mail subject> | | Edit the email subject |
| | | attack | send-alert <yes no> | | Activate or deactivate the firewall DoS attacks notification emails |
| | | | block <yes no> | | Yes: Block the traffic when exceeds the tcp-max-incomplete threshold |
| | | | | | No: Delete the oldest half-open session when exceeds the tcp-max-incomplete threshold |
| | | | block-minute <0~255> | | Only valid when sets 'Block' to yes. The unit is minute |

| | | | | | |
|--|--|------------|-----------------------------------|---|--|
| | | | minute-high <0~255> | | The threshold to start to delete the old half-opened sessions to minute-low |
| | | | minute-low <0~255> | | The threshold to stop deleting the old half-opened session |
| | | | max-incomplete-high <0~255> | | The threshold to start to delete the old half-opened sessions to max-incomplete-low |
| | | | max-incomplete-low <0~255> | | The threshold to stop deleting the half-opened session |
| | | | tcp-max-incomplete <0~255> | | The threshold to start executing the block field |
| | | set <set#> | name <desired name> | | Edit the name for a set |
| | | | default-permit <forward block> | | Edit whether a packet is dropped or allowed when it does not match the default set |
| | | | icmp-timeout <seconds> | | Edit the timeout for an idle ICMP session before it is terminated |
| | | | udp-idle-timeout <seconds> | | Edit the timeout for an idle UDP session before it is terminated |
| | | | connection-timeout <seconds> | | Edit the wait time for the SYN TCP sessions before it is terminated |
| | | | fin-wait-timeout <seconds> | | Edit the wait time for FIN in concluding a TCP session before it is terminated |
| | | | tcp-idle-timeout <seconds> | | Edit the timeout for an idle TCP session before it is terminated |
| | | | pnc <yes no> | | PNC is allowed when 'yes' is set even there is a rule to block PNC |
| | | | log <yes no> | | Switch on/off sending the log for matching the default permit |
| | | | rule <rule#> | permit <forward block> | Edit whether a packet is dropped or allowed when it matches this rule |
| | | | | active <yes no> | Edit whether a rule is enabled or not |
| | | | | protocol <0~255> | Edit the protocol number for a rule. 1=ICMP, 6=TCP, 17=UDP... |
| | | | | log <none match not-match both> | Sending a log for a rule when the packet none matches not match both the rule |
| | | | | alert <yes no> | Activate or deactivate the notification when a DoS attack occurs or there is a violation of any alert settings. In case of such instances, the function will send an email to the SMTP destination address and log an alert. |
| | | | | srcaddr-single <ip address> | Select and edit a source address of a packet which complies to this rule |
| | | | | srcaddr-subnet <ip address> <subnet mask> | Select and edit a source address and subnet mask if a packet which complies to this rule. |
| | | | | srcaddr-range <start ip address> <end ip address> | Select and edit a source address range of a packet which complies to this rule. |
| | | | | destaddr-single <ip address> | Select and edit a destination address of a packet which complies to this rule |
| | | | | destaddr-subnet <ip address> <subnet mask> | Select and edit a destination address and subnet mask if a packet which complies to this rule. |
| | | | | destaddr-range <start | Select and edit a destination address range of a |

| | | | | | |
|--------|----------|------------|--------------|--|---|
| | | | | ip address> <end ip address> | packet which complies to this rule. |
| | | | | tcp destport-single <port#> | Select and edit the destination port of a packet which comply to this rule. For non-consecutive port numbers, the user may repeat this command line to enter the multiple port numbers. |
| | | | | tcp destport-range <start port#> <end port#> | Select and edit a destination port range of a packet which comply to this rule. |
| | | | | udp destport-single <port#> | Select and edit the destination port of a packet which comply to this rule. For non-consecutive port numbers, users may repeat this command line to enter the multiple port numbers. |
| | | | | udp destport-range <start port#> <end port#> | Select and edit a destination port range of a packet which comply to this rule. |
| | | | | desport-custom <desired custom port name> | Type in the desired custom port name |
| delete | firewall | e-mail | | | Remove all email alert settings |
| | | attack | | | Reset all alert settings to defaults |
| | | set <set#> | | | Remove a specified set from the firewall configuration |
| | | set <set#> | rule <rule#> | | Remove a specified rule in a set from the firewall configuration |
| insert | firewall | e-mail | | | Insert email alert settings |
| | | attack | | | Insert attack alert settings |
| | | set <set#> | | | Insert a specified rule set to the firewall configuration |
| | | set <set#> | rule <rule#> | | Insert a specified rule in a set to the firewall configuration |
| cli | | | | | Display the choices of command list. |

Firewall Related Command

[Home](#)

| Command | | | | Description |
|---------|----------|-------------|----------|---|
| sys | | | | |
| | firewall | | | |
| | | acl | | |
| | | | disp | Display specific ACL set # rule #, or all ACLs. |
| | | active | <yes/no> | Active firewall or deactivate firewall |
| | | cnt | | |
| | | | disp | Display firewall log type and count. |
| | | | clear | Clear firewall log count. |
| | | pktdump | | Dump the 64 bytes of dropped packet by firewall |
| | | update | | Update firewall |
| | | dynamicrule | | |
| | | tcprst | | |
| | | | rst | Set TCP reset sending on/off. |
| | | | rst113 | Set TCP reset sending for port 113 on/off. |
| | | | display | Display TCP reset sending setting. |
| | | icmp | | |
| | | dos | | |
| | | | smtp | Set SMTP DoS defender on/off |

ZyXEL Confidential

| | | | |
|--|--------|----------|---|
| | | display | Display SMTP DoS defender setting. |
| | | ignore | Set if firewall ignore DoS in lan/wan/dmz/wlan |
| | ignore | | |
| | | triangle | Set if firewall ignore triangle route in lan/wan/dmz/wlan |

SMT Related command

[Home](#)

| No | Command | Description | Comment |
|----|---|---|----------------|
| | sys bridge [on off] | Set system bridge on/off | Menu 1 |
| | sys routeip [on off] | Set system IP routing on/off | Menu 1 |
| | sys hostname [hostname] | Set system name | Menu 1 |
| | sys display | Display hostname, routing/bridge mode information in menu 1 | Display Menu 1 |
| | sys default | Load All Default Settings Except LAN and DHCP. | |
| | sys save | Save all the parameters which will include menu1, menu 3.2 LAN, menu 4 or menu 11 WAN, menu 12 static route, menu 15 NAT server set, menu 21 filter sets, menu 22 SNMP, menu 24.11 remote management and 3.5 Wireless LAN | |
| | | | |
| | wan backup mechanism [dsl icmp] | Set wan backup mechanism to DSL link or ICMP | Menu 2 |
| | wan backup addr [index] [IP addr] | Set wan ip address <index> | Menu 2 |
| | wan backup tolerance [number] | Set keepalive fail tolerance | Menu 2 |
| | wan backup recovery [interval(sec)] | Set recovery interval | Menu 2 |
| | wan backup timeout [number] | Set ICMP timeout | Menu 2 |
| | wan backup save | Save wan backup related parameters | Menu 2 |
| | wan backup display | Display wan backup configurations | Menu 2 |
| | wan tredir active [on off] | Set traffic redirect on/off | Menu 2.1 |
| | wan tredir ip [IP addr] | Set traffic redirect gateway IP address | Menu 2.1 |
| | wan tredir metric [number] | Set traffic redirect metric | Menu 2.1 |
| | wan tredir save | Save traffic redirect related parameters ** Have to apply “wan backup save” command thereafter | Menu 2.1 |
| | wan tredir display | Display traffic redirect configurations | Menu 2.1 |
| | | | |
| | lan index [1 2 3] 1: Select main LAN Interface 2: Select IP Alias 1 3: Select IP Alias 2 | Select a LAN interface to edit | Menu 3.2 |
| | lan active [on off] | Turn on or off on IP Alias Interface | Menu 3.2.1 |
| | lan ipaddr [address] [subnet mask] | Set LAN IP address and subnet mask Example: > lan ipaddr 192.168.1.1 255.255.255.0 | Menu 3.2 |
| | lan rip [none in out both] [rip1 rip2b rip2m] | Set LAN IP RIP mode and RIP version, if you choose none in the first parameter, the second parameter is also necessary | Menu 3.2 |
| | lan multicast [none igmpv1 igmpv2] | Set LAN IP multicast mode | Menu 3.2 |
| | lan filter [incoming outgoing] [tcpip generic] [set#1] [set#2] [set#3] [set#4] | Set LAN filter to be incoming/outgoing or protocol /device and the filter set could be 1-12, 0 means empty Example: Lan filter incoming tcpip 1 0 0 0 | Menu 3.1 |
| | lan dhcp mode [server relay none] | Set DHCP mode to be “server”, “relay”, “none” | Menu 3.2 |
| | lan dhcp server dnsserver [pri dns] [sec dns] | Set primary and secondary LAN DNS server | Menu 3.2 |
| | lan dhcp server pool [start-address] [num] | Set DHCP start address and pool size | Menu 3.2 |
| | lan dhcp server gateway [IP address] | Set DHCP gateway | Menu 3.2 |
| | lan dhcp server netmask [subnet mask] | Set DHCP subnet mask | Menu 3.2 |

ZyXEL Confidential

| | | | |
|--|---|---|-----------------|
| | lan dhcp server leasetime [second] | Set DHCP lease time | Menu 3.2 |
| | lan dhcp server renewalttime [second] | Set DHCP renew time | Menu 3.2 |
| | lan dhcp server rebindtime [second] | Set DHCP rebind time | Menu 3.2 |
| | lan dhcp relay server [IP address] | Set IP address of DHCP relay server | Menu 3.2 |
| | lan display | Display LAN or IP alias parameters | Display Menu 3 |
| | lan clear | Clear the Working Buffer | |
| | lan save | Save LAN related parameters | |
| | | | |
| | wan node index [1-8] | Set the node pointer to specific wan profile. If you want to set WAN profile, please use this command first, system will use the index number for pointing to specific PVC (remote node), and for consequent commands reference, if index = 1 means it's ISP node | Menu 11.1 |
| | wan node clear | Clear the parameters of the temporary WAN profile | Menu 11.1 |
| | wan node ispname [ISP name] | Enable the name of wan node | Menu 11.1 |
| | wan node enable | Enable the wan profile | Menu 11.1 |
| | wan node disable | Disable the wan profile | Menu 11.1 |
| | wan node encaps [1483 pppoe pppoe enet] | Set the wan protocol | Menu 11.1 |
| | wan node mux [vc llc] | Set the wan multiplex | Menu 11.1 |
| | wan node ppp authen [chap pap both] | Set PPP authentication type | Menu 11.1 |
| | wan node ppp username [name] | Set PPP username | Menu 11.1 |
| | wan node ppp password [password] | Set PPP password | Menu 11.1 |
| | wan node service [name] | Set PPPoE service name | Menu 11.1 |
| | wan node bridge [on off] | Set the wan bridge mode | Menu 11.1 |
| | wan node routeip [on off] | Set the wan IP routing mode | Menu 11.1 |
| | wan node callsch [set1#][set2#][set3#][set4#] | Set call schedule set, set number 0 means empty | Menu 11.1 |
| | wan node nailedup [on off] | Set nailed up connection on/off | Menu 11.1 |
| | wan node vpi [num] | Set the wan vpi. Range : 0~255 | Menu 11.6 |
| | wan node vci [num] | Set the wan vci. Range : 32~65535 | Menu 11.6 |
| | wan node qos[ubr cbr] | Set the wan QOS type to be UBR or CBR | Menu 11.6 |
| | wan node pcr [num] | Set the wan PCR value | Menu 11.6 |
| | wan node scr [num] | Set the wan SCR value | Menu 11.6 |
| | wan node mbs [num] | Set the wan MBS value | Menu 11.6 |
| | wan node wanip [static dynamic] [address] | Set the wan IP address | Menu 11.3 |
| | wan node remoteip [address] [subnet mask] | Set the remote gateway IP address and subnet mask | Menu 11.3 |
| | wan node nat [off sua full] [address mapping #] | Set type wan NAT mode to be off or SUA or Full feature | Menu 11.3 |
| | wan node rip [none in out both] [rip1 rip2b rip2m] | Set the wan RIP mode and RIP version | Menu 11.3 |
| | wan node multicast [none igmpv1 igmpv2] | Set the wan IP multicast mode | Menu 11.3 |
| | wan node filter [incoming outgoing] [tcpip generic] [set #1] [set #2] [set #3] [set #4] | Set WAN filter, incoming or outgoing can be specified, and filter set can be 1-12, value 0 means empty | Menu 11.5 |
| | wan node save | Save the related parameters of WAN node | |
| | wan node display | Display WAN profile configuration in buffer | Display Menu 11 |
| | | | |
| | ip route addrom index [Rule #] | Select a Static Route index 1-16 to edit | Menu 12.1 |
| | ip route addrom name [Name] | Set Rule Name | Menu 12.1 |
| | ip route addrom active [on off] | Set Active or Inactive Flag | Menu 12.1 |
| | ip route addrom set [dest address/ mask bits] [gateway] [metric] | Set IP static route Example: > ip ro addrom set 192.168.1.33/24 192.168.1.1 2 | Menu 12.1 |

ZyXEL Confidential

| | | | |
|--|---|---|---------------------|
| | ip route addrom private [yes no] | Set Private Flag | Menu 12.1 |
| | ip route addrom disp | Display both working buffer and Editing Entry | Menu 12.1 |
| | ip route addrom freememory | Discard all changes | Menu 12.1 |
| | ip route addrom save | Save edited settings | Menu 12.1 |
| | ip route addrom clear [Index #] | Clear Static Route Index | Menu 12.1 |
| | | | |
| | ip nat addrmap map [map#] [set name] | Select NAT address mapping set and set mapping set name, but set name is optional Example: > ip nat addrmap map 1 myset | Menu 15.1 |
| | ip nat addrmap rule [rule#] [insert edit] [type] [local start IP] [local end IP] [global start IP] [global end IP] [server set #] | Set NAT address mapping rule. If the “type” is not “inside-server” then the “type” field will still need a dummy value like “0”. Type is 0 - 4 = one-to-one, many-to-one, many-to-many-overload, many-to-many-non overload, inside-server Example: > ip nat addrmap rule 1 edit 3 192.168.1.10 192.168.1.20 192.168.10.56 192.168.1.56 0 | Menu 15.1 |
| | ip nat addrmap clear [map#] [rule#] | Clear the selected rule of the set | Menu 15.1 |
| | ip nat addrmap freememory | Discard Changes | Menu 15.1 |
| | ip nat addrmap disp | Display nat set information | Menu 15.1 |
| | ip nat addrmap save | Save settings | Menu 15.1 |
| | ip nat server load [set#] | Load the server sets of NAT into buffer | Menu 15.2 |
| | ip nat server disp [1] | “disp 1” means to display the NAT server set in buffer, if parameter “1” is omitted, then it will display all the server sets | Menu 15.2 |
| | ip nat server save | Save the NAT server set buffer into flash | Menu 15.2 |
| | ip nat server clear [set#] | Clear the server set [set#], must use “save” command to let it save into flash | Menu 15.2 |
| | ip nat server edit [rule#] active | Activate the rule [rule#], rule number is 1 to 24, the number 25-36 is for UPNP application | Menu 15.2 |
| | ip nat server edit [rule#] svrport <start port> <end port> | Configure the port range from <start port > to <end port> | Menu 15.2 |
| | ip nat server edit [rule#] remotehost <start IP> <end IP> | Configure the IP address range of remote host (Leave it to be default value if you don’t need this command) | Menu 15.2 |
| | ip nat server edit [rule#] leasetime <seconds> | Configure the lease time (Leave it to be default value if you don’t want this command) | Menu 15.2 |
| | ip nat server edit [rule#] rulename <string> | Configure the name of the rule (Leave it to be default value if you don’t want this command) | Menu 15.2 |
| | ip nat server edit [rule#] forwardip <IP address> | Configure the LAN IP address to be forwarded | Menu 15.2 |
| | ip nat server edit [rule#] protocol <TCP UDP ALL> | Configure the protocol to be used TCP , UDP or ALL (it must be capital) | Menu 15.2 |
| | sys filter set index [set#] [rule#] | Set the index of filter set rule, you may apply this command first before you begin to configure the filter rules | Menu 21 filter sets |
| | sys filter set name [set name] | Set the name of filter set | Menu 21 filter sets |
| | sys filter set type [tcpip generic] | Set the type of filter rule | Menu 21 filter sets |
| | sys filter set enable | Enable the rule | Menu 21 filter sets |
| | sys filter set disable | Disable the rule | Menu 21 filter sets |
| | sys filter set protocol [protocol #] | Set the protocol ID of the rule | Menu 21 filter sets |
| | sys filter set sourceroute [yes no] | Set the sourceroute yes/no | Menu 21 filter sets |
| | sys filter set destip [address] [subnet mask] | Set the destination IP address and subnet mask of the rule | Menu 21 filter sets |
| | sys filter set destport [port#] [compare type = | Set the destination port and compare type (compare type | Menu 21 filter sets |

ZyXEL Confidential

| | | | |
|--|---|--|----------------------------------|
| | none equal notequal less greater] | could be 0(none) 1(equal) 2(not equal) 3(less) 4(greater)) | |
| | sys filter set srcip [address] [subnet mask] | Set the source IP address and subnet mask | Menu 21 filter sets |
| | sys filter set srcport [port#] [compare type = none equal not equal less greater] | Set the source port and compare type (compare type could be 0(none) 1(equal) 2(not equal) 3(less) 4(greater)) | Menu 21 filter sets |
| | sys filter set tcpEstab [yes no] | Set TCP establish option | |
| | sys filter set more [yes no] | Set the more option to yes/no | Menu 21 filter sets |
| | sys filter set log [type 0-3= none match notmatch both] | Set the log type (it could be 0-3 =none, match, not match, both) | Menu 21 filter sets |
| | sys filter set actmatch[type 0-2 = checknext forward drop] | Set the action for match | Menu 21 filter sets |
| | sys filter set actnomatch [type 0-2 = checknext forward drop] | Set the action for not match | Menu 21 filter sets |
| | sys filter set offset [#] | Set offset for the generic rule | Menu 21, it's for generic filter |
| | sys filter set length [#] | Set the length for generic rule | Menu 21, it's for generic filter |
| | sys filter set mask [#] | Set the mask for generic rule | Menu 21, it's for generic filter |
| | sys filter set value [(depend on length in hex)] | Set the value for generic rule | Menu 21, it's for generic filter |
| | sys filter set clear | Clear the current filter set | Menu 21 |
| | sys filter set save | Save the filter set parameters | |
| | sys filter set display [set#][rule#] | Display Filter set information. W/o parameter, it will display buffer information. | |
| | sys filter set freememory | Discard Changes | |
| | | | |
| | sys snmp disp | Display SNMP parameters | Menu 22 |
| | sys snmp get [community] | Set the community string of get | Menu 22 SNMP |
| | sys snmp set [community] | Set the community string of set | Menu 22 SNMP |
| | sys snmp trusthost [IP address] | Set the IP address of trusted host | Menu 22 SNMP |
| | sys snmp trap community [community] | Set the community string of trap | Menu 22 SNMP |
| | sys snmp trap destination [IP address] | Set the destination address of trap | Menu 22 SNMP |
| | sys snmp discard | Discard changes | |
| | sys snmp clear | Clear Working Buffer | |
| | sys snmp save | Set the SNMP parameters | Menu 22 SNMP |
| | | | |
| | sys password [new password] | Set system password [save immediately] | Menu 23 system password |
| | | | |
| | sys baud [1-5] | Index 1,2,3 will be 38400,19200, 9600, 57600, 115200 bps [save immediately] | Menu 24.2.2 console speed |
| | | | |
| | sys server load | Load setting before editing | |
| | sys server access [ftp telnet web] [access type] | Set the server access type to be 0: ALL, 1: None, 2:LAN only, 3:WAN only | Menu 24.11 remote management |
| | sys server port [ftp telnet web] [port] | Set the server port number | Menu 24.11 remote management |
| | sys server secureip[ftp telnet web] [address] | Set the server security IP address | Menu 24.11 remote management |
| | sys server disp [1] | Display server settings, [1] means display buffer | |
| | sys server save | Save the embedded server (remote management) parameters | |